



The SL DI 4 XLR Dante™ interface

Instruction manual



The SL DI 4 XLR Dante™ interface

The SL DI 4 XLR is a Dante™ interface with four inputs. This lets you integrate wireless microphone receivers or mic/line inputs into a Dante™ system. The compact design of the SL DI 4 XLR allows it be mounted almost anywhere, enabling close placement to audio sources and thus reducing the need for interference-prone analog cables.






Product overview and LED indicators – front panel

- 1 **P48** LEDs indicate, for each individual XLR input (**IN 1**, **IN 2**, **IN 3**, **IN 4**), whether the phantom power is activated
- 2 **+45, +30, +15** LEDs indicate the gain settings for each XLR input
- 3 **PAD** LEDs indicate, for each individual XLR input, whether the -12 dB pad function is activated
- 4 **POWER** LED lights up when the power supply is active

Product overview and connections – rear panel



- 5 **PWR LINK** input and output Terminals for daisy-chaining the power supply to other devices
- 6 **DC IN** socket input socket for an optional power supply unit (Sennheiser NT 12-50CS)
- 7 **DATA** socket Dante™ Ethernet socket
- 8 **POE + DATA** socket Dante™ Ethernet socket with PoE function
- 9 analog XLR inputs (**IN 1**, **IN 2**, **IN 3**, **IN 4**) analog audio inputs




Powering the SL DI 4 XLR

There are two options to power the SL DI 4 XLR.

Power supply via Ethernet cable

To power the SL DI 4 XLR via Ethernet:


- ▷ Use an Ethernet cable (CAT-5 or higher) to connect the **POE + DATA** socket of the SL DI 4 XLR to a PoE port of a PoE-enabled network device.
The **POWER** LED lights up when the power supply is established.



Power supply via the optional Sennheiser NT 12-50CS power supply unit

To power the SL DI 4 XLR via the optional NT 12-50CS power supply unit:

- ▷ Connect the NT 12-50CS power supply unit to the **DC IN** socket of the SL DI 4 XLR.
The **POWER** LED lights up when the power supply is established





Daisy-chaining the power supply

The **PWR LINK IN** and **OUT** terminals allow you to daisy-chain the power supply to additional devices.

The number of devices that can be daisy-chained is limited.

- NT 12-50CS **power supply** -> maximum of **3 devices**.
- **Power over Ethernet** -> maximum of **2 devices**



WARNING!

DANGER OF INJURY DUE TO MISSING OVERLOAD PROTECTION!

IF THE DAISY-CHAINING OF THE POWER SUPPLY IS NOT DONE PROPERLY, THIS MAY CAUSE INJURY DUE TO ELECTRIC SHOCK.

- ▷ Only have the daisy-chaining of the power supply done by a qualified specialist.


Connecting audio signals

You can connect a total of four analog audio signals (e.g. from microphone receivers (SL Rack Receiver DW) or wired microphones) to the SL DI 4 XLR.

You can change the settings for the respective microphone input using the SL DI CONTROL software (see „Configuring the SL DI 4 XLR using the SL DI CONTROL software“).

To connect analog audio signals to the SL DI 4 XLR:

- ▷ Use an XLR-3 cable to connect the audio device to one of the four XLR inputs.



Via the **DATA** and **POE + DATA** Ethernet sockets, the audio signals are routed, using Dante™, to a Dante™-enabled device.

The destination of the Dante™ stream is configured using a Dante™ software controller. This controller is not part of the SL DI CONTROL software..




Configuring the SL DI 4 XLR using the SL DI CONTROL software

All settings of the input and outputs of the SL DI 4 XLR are adjusted using the SL DI CONTROL software. You can download the software at www.sennheiser.com on the product page for the SL DI 4 XLR or in the global download area on the Sennheiser website at www.sennheiser.com/download.

- ▷ Install the software on a network-enabled Windows PC.

Starting the SL DI CONTROL software

After opening the software, the start screen is shown:




Selecting the network interface

If you have a network with several interfaces, you can select the network interface:

- ▷ Click on the network icon on the left of the navigation bar.



- ▷ Select the desired network interface.




- ▷ Click on OK.



Establishing a connection to a SL DI 4 XLR

To establish a connection to a SL DI 4 XLR:

- ▷ Select the desired SL DI 4 XLR from the drop-down list on the right of the navigation bar..
The drop-down list shows all SL DI 4 XLR devices that are in the same network as the PC on which the SL DI CONTROL software is running.



- ▷ After having selected the desired device, click on Connect.

The connection to the selected device is established and the following configuration window opens:



Changing the settings

The configuration window allows you to adjust the following settings for each analog XLR input (IN 1, IN 2, IN 3, IN 4):

Gain

- ▷ Select the level adjustment for the desired input from the drop-down list

-12 dB	Attenuation of -12 dB. At the front of the SL DI 4 XLR, the PAD LED of the selected input lights up.
0 dB	No LED lights up.
+15 dB	At the front of the SL DI 4 XLR, the +15 LED of the selected input lights up.
+30 dB	At the front of the SL DI 4 XLR, the +30 LED of the selected input lights up.
+45 dB	At the front of the SL DI 4 XLR, the +45 LED of the selected input lights up.

Phantom



- ▷ Tick the check box to activate the phantom power for the desired input.
At the front of the SL DI 4 XLR, the P48 LED of the selected input lights up.




Saving and loading settings


You can save the settings made as presets or as files.

To save the settings:

- ▷ Click on the folder icon on the left of the navigation bar.



The following dialog box opens.



To save the settings as a preset:

- ▷ From the drop-down list in the Device Preset box, select a preset to which you want to save the settings.
The settings can be saved in 10 presets.
- ▷ Click Save to Device.

To load the settings saved as a preset:

- ▷ Select the desired preset from the drop-down list in the Device Preset box.
- ▷ Click Recall from Device.

To save the settings as a file:

- ▷ Click on Save to File in the Device Preset box..
- ▷ Select a location and a file name.
The file is saved with the extension *.cfg.

To load the settings from a file:

- ▷ Click Load from File in the Device Preset box.
- ▷ Open the location of the desired file.



Identifying devices

If you are using several SL DI 4 XLR devices and want to know which device in the software corresponds to which hardware in your installation, you can use the Identify function.

- ▷ Tick the Identify check box at the right of the navigation bar.



All four **PAD** LEDs flash on the corresponding SL DI 4 XLR.


The Dante Debug Mode

In Dante Debug Mode, the LEDs at the front of the SL DI 4 XLR indicate the diagnostic status.

After start-up of the SL DI 4 XLR, the diagnostic status is displayed for approx. 20 seconds before the level and phantom power settings are shown.

To manually display the diagnostic status::


- ▷ Tick the Dante Debug Mode check box in the lower left corner of the configuration window.






At the front of the SL DI 4 XLR, the **PAD** and **+15** LEDs of the **IN 1**, **IN 3** and **IN 4** inputs indicate the following status information:


IN 1 input: SYNC




The **PAD** and the **+15** LED of the **IN 1** input light up:: PTP is being synchronized.



The **+15** LED of the **IN 1** input lights up PTP Error / No PTP Sync / PTP deactivated




The **PAD** LED of the **IN 1** input lights up: PTP Slave, with PTP-Sync




The **PAD** LED of the **IN 1** input flashes: PTP Master



Eingang **IN 3**: ERR




The **PAD** and **+15** LEDs of the **IN 3** input light up: Capability is corrupted




The **+15** LED of the **IN 3** input lights up: Memory Stack Overflow

Eingang **IN 4**: SYS



The **+15** LED of the **IN 4** input lights up: System starts up



The **PAD** LED of the **IN 4** input lights up: System is ready for operation