

SENNHEISER



**Frequenzbereich / Frequency range /
Bande de fréquence / Rango de frecuencias**

BC 670 – 694 MHz

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Printed in Taiwan, Publ. 10/18, 581372/A01

BC 670 – 694 MHz

EBU TV channel	Ch. 46 (670-678 MHz)	Ch. 47 (678-686 MHz)	Ch. 48 (686-694 MHz)	
----------------	----------------------	----------------------	----------------------	--

Channel		Bank 1	Bank 2	Bank 3	Bank 4	Bank 5	Bank 6	Bank 7	Bank 8	
XS WIRELESS 2 **	XS WIRELESS 1 *	1	670.200	676.250	682.350	688.400	670.400	676.350	682.250	688.200
		2	670.600	676.650	682.750	688.800	671.200	676.950	682.850	689.200
		3	671.100	677.150	683.250	689.300	672.400	678.250	683.650	690.300
		4	671.800	677.850	683.950	689.900	673.100	679.050	685.150	690.900
		5	673.100	678.850	684.950	690.900	674.100	680.050	686.150	692.200
		6	673.700	680.350	685.750	691.600	674.700	680.750	686.850	692.900
		7	674.800	681.150	687.050	692.800	675.200	681.250	687.350	693.400
		8	675.800	681.750	687.650	693.600	675.600	681.650	687.750	693.800
		9	684.350	670.650	676.650	671.500	680.500	670.150	677.850	671.350
		0* / 10**	685.850	683.050	690.950	673.300	688.300	671.550	679.850	677.350
		11	686.650	684.150	692.450	675.700	690.700	673.050	680.950	678.150
		12	692.650	686.150	693.850	683.500	692.500	687.350	693.350	679.650



Informieren Sie sich bei Ihrer zuständigen Zulassungsbehörde über die erlaubten Sendefrequenzen, Sendeleistungen und beantragen eine Betriebserlaubnis für diese Funkanlage.

Please contact your radio licensing authority in your country, who will advise you on the available frequencies and transmitter power requirements.