

SENNHEISER



**Frequenzbereich / Frequency range /
Bande de fréquence / Rango de frecuencias**

B 614 – 638 MHz

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Publ. 02/17, 571318/A02

B 614 – 638 MHz

US TV channel	Ch. 38 (614-620 MHz)	Ch. 39 (620-626 MHz)	Ch. 40 (626-632 MHz)	Ch. 41 (632-638 MHz)
EBU TV channel	Ch. 39 (614-622 MHz)	Ch. 40 (622-630 MHz)	Ch. 41 (630-638 MHz)	

Channel		Bank 1	Bank 2	Bank 3	Bank 4	Bank 5	Bank 6	Bank 7	Bank 8	
XS WIRELESS 2 **	XS WIRELESS 1 *	1	614.200	620.250	626.350	632.400	614.400	620.350	626.250	632.200
		2	614.600	620.650	626.750	632.800	615.200	620.950	626.850	633.200
		3	615.100	621.150	627.250	633.300	616.400	622.250	627.650	634.300
		4	615.800	621.850	627.950	633.900	617.100	623.050	629.150	634.900
		5	617.100	622.850	628.950	634.900	618.100	624.050	630.150	636.200
		6	617.700	624.350	629.750	635.600	618.700	624.750	630.850	636.900
		7	618.800	625.150	631.050	636.800	619.200	625.250	631.350	637.400
		8	619.800	625.750	631.650	637.600	619.600	625.650	631.750	637.800
		9	628.350	614.650	620.650	615.500	624.500	614.150	621.850	615.350
		0* / 10**	629.850	627.050	634.950	617.300	632.300	615.550	623.850	621.350
	11	630.650	628.150	636.450	619.700	634.700	617.050	624.950	622.150	
	12	636.650	630.150	637.850	627.500	636.500	631.350	637.350	623.650	



Informieren Sie sich bei Ihrer zuständigen Zulassungsbehörde über die erlaubten Sendefrequenzen, Sendeleistungen und beantragen eine Betriebserlaubnis für diese Funkanlage.

Please contact your radio licensing authority in your country, who will advise you on the available frequencies and transmitter power requirements.